Part No. 01/3366 September 2009

NEXYGEN[™] PLUS Materials Testing Software for Lloyd Instruments[™] EZ and PLUS Series Testing Machines

۲

Quick Start Guide





۲

۲

WARRANTY

AMETEK warrants for a period of ninety (90) days from the date of delivery to the Licencee that the Licenced Materials will conform to Lloyd Instruments' published specifications and release current at the time of delivery. AMETEKs' sole obligation, and the Licencee's sole remedy, shall be for AMETEK to exert its reasonable efforts to correct such alleged defects and to supply the Licencee with a changed version within a reasonable time after Licencee notifies AMETEK in writing of any alleged defect. This warranty does not cover modifications to the Licencee Material made by any person not employed by AMETEK, or any defects caused by or otherwise related to such modifications. Except for the express warranty stated above, AMETEK grant no warranties, either express or implied, on any Licencee material including, but not limited to, all warranties of merchantability and fitness for a particular purpose. Licencee shall bear the risk of loss or damage to the Licenced Material whilst under its control.

TRADEMARKS

AMETEK is a registered trademarks of AMETEK, Inc. LLOYD INSTRUMENTS is a trademark of AMETEK, Inc. NEXYGEN is a trademark of AMETEK, Inc. DAVENPORT is a trademark of AMETEK, Inc. Other trademarks are the property of their respective owners.

SUPPORT

()

AMETEK Lloyd Instruments Ltd Steyning Way Bognor Regis West Sussex UK PO22 9ST

 Tel:
 +44 (0) 1243 833 370

 Fax:
 +44 (0) 1243 833 401

 Email:
 techsupport@ametek.co.uk

 Internet:
 www.lloyd-instruments.co.uk

AMETEK Measurement and Calibration Technologies 8600 Somerset Drive Largo, FL 33773 USA

 Tel:
 +1-727-536-7831

 Tel:
 +1-800-527-9999 (within USA only)

 Email:
 chatillon.fl-lar@ametek.com

2 NEXYGEN PLUS Quick Start Guide

()

LICENSE AGREEMENT

This Software Licence Agreement ("Agreement") is made and entered in to by and between AMETEK and the Customer, hereinafter referred to as the "Licensee". AMETEK hereby grants and the Licensee hereby accepts a non-exclusive, non-transferable Licence to use the Licensed Material, subject to the following terms and conditions.

DEFINITIONS

"Licensed Material" is each product furnished by AMETEK to the Licensee and includes supporting materials and any related updated product or product portion furnished by AMETEK. "User System" is a single CPU.

LICENSE

The License granted hereunder authorizes the Licensee, on a non-exclusive basis, to use the Licensed Material for use on computers which are interfaced with instruments manufactured or sold by AMETEK. The use by the Licensee of Licenced Material supplied by AMETEK shall be deemed to be an acceptance of the terms of this License Agreement by both parties.

REPRODUCTION RIGHTS

Licensee may make one copy of the Licensed Materials for archival (backup) purposes. Licensee may copy the Licensed Material on to a hard disk which is the integral hardware component of the single computer on which the Licensed Material is to be used. In this case, the original delivery media becomes the backup copy and the working copy is that which resides on the hard disk.

Licensee agrees not to remove AMETEK copyright notices and other legends both in and on every copy of the Licensed Material, in any form, including partial copies.

Licensee must not modify the Licensed Material or incorporate it into any other software without the express written permission of AMETEK.

SECURITY AND TRANSFERABILITY

The Licensee agrees not to provide, sub Licence, use in a time-sharing service or otherwise make available the Licensed Material or any portion thereof, in any form, to any person other than the Licensee or AMETEK employees without the prior written consent of AMETEK.

The Licensee agrees to take all reasonable steps, both during and after the terms of this License Agreement, to ensure that no unauthorized person shall have access to the Licensed Material, and that no unauthorized copy, in whole or in part, shall be made.

TITLE

()

Nothing contained in this License Agreement shall directly or indirectly, by implication or otherwise, be construed as an assignment or grant to the Licensee of any right, title or interest in the copyrights, patents or trade secrets of AMETEK, all rights related thereto being reserved by AMETEK except for the non-exclusive License granted hereunder to the Licensee as expressly provided herein.

LIABILITY

AMETEK will not be responsible for any direct, incidental or consequential damages, including, but not limited to Loss of Profits or in any way for any liability arising out of this Agreement, resulting from the use of the Licensed Materials save that nothing in this Agreement affects AMETEK's liability for death or personal injury arising out of AMETEK's negligence.

۲

NEXYGEN PLUS Quick Start Guide 3

TERMS AND TERMINATION

The terms of this Agreement and any License granted hereunder shall begin on the date of supply by AMETEK of the Licensed Material, and shall run until the Licensee discontinues use of all Licensed Materials, so long and only during such period, as the Licencee complies with the terms and conditions set forth herein. This Agreement and any License granted hereunder may be terminated by AMETEK, in addition to any other remedies that it may have, if Licensee fails to comply with any of the terms and conditions of this Agreement, provided written notice describing the default is given to the Licensee. The Licensee shall have a period of thirty (30) days from receipt of such notice to certify in writing that it has remedied the default. If AMETEK does not receive such certification within this thirty (30) day period, AMETEK may give the Licensee notification of termination. Within ten (10) days of notification of such termination or within thirty (30) days after the Licensee has discontinued use of all Licensed Material, Licensee shall destroy or return to AMETEK all the License Material and all reproductions in whole or in part in Licensee's possession or under Licensee's control and shall so certify in writing to AMETEK.

GENERAL

()

Any variation of this Agreement shall be in writing and signed by or on behalf of the parties.

Each party acknowledges that in entering into this Agreement it does not rely on any representation warranty or other provision except as expressly provided herein.

No delay or omission of either party in exercising any right hereunder shall impair such right or is to be construed as a waiver thereof.

4 NEXYGEN PLUS Quick Start Guide

()

ICONS



WARNING

The raised hand icon warns of a situation or condition that may lead to personal injury or death. Do not proceed until the warning is read and thoroughly understood. Warning messages are shown in bold type.



DANGEROUS VOLTAGE

The lightning icon warns of the presence of an uninsulated dangerous voltage within the product enclosure that might be of sufficient magnitude to cause serious shocks or death. Never open the enclosures unless you are an authorized and qualified LLOYD INSTRUMENTS' service personnel. Never open any enclosure when power is connected to the system or its components.



CAUTION

The exclamation point icon indicates a situation or condition that may lead to equipment malfunction or damage. Do not proceed until the caution message is read and thoroughly understood. Caution messages are shown in bold type.



()

NOTE

The note icon indicates additional or supplementary information about the action, activity or concept. Notes are shown in bold type.

۲

CAUTION

HIGH FORCES ARE OFTEN INVOLVED WITH THE MATERIAL TESTING PROCESSES.

MACHINES ARE POWERED BY MAINS SUPPLY VOLTAGE

CLASS 1 PRODUCT, MUST BE CONNECTED TO A MAINS SOCKET OUTLET WITH A PROTECTIVE EARTH CONNECTION

DO NOT POSITION THE EQUIPMENT SO THAT IT IS DIFFICULT TO OPERATE THE DISCONNECT DEVICE (MACHINE MAINS INLET SOCKET)

IF THE EQUIPMENT IS USED IN A MANOR NOT SPECI-FIED BY THE MANUFACTURER, THE PROTECTION PROVIDED BY THE EQUIPMENT MAY BE IMPAIRED

TO MAINTAIN ALL ASPECTS OF THE SPECIFICATION, ONLY LLOYD INSTRUMENTS APPROVED ACCES-SORIES CONNECTIONS AND COMPONENTS SHOULD BE USED

STRICTLY ADHERE TO ALL SPECIFIED SAFETY PROCEDURES

READ THIS MANUAL BEFORE USING THE MATERIALS TESTING MACHINE.

General Safety

General safety precautions must be followed when using this AMETEK product. Failure to observe precautions and warnings may result in damage to the equipment, or injury to personnel.

It is understood that safety rules within companies vary. If a conflict exists between the material contained in all AMETEK User's Guides and the rules of a company using an AMETEK product, the more stringent rules should take precedence.

NEXYGEN PLUS Quick Start Guide 5

1.0 CREATING A TEST FILE

1.1 CREATING A TEST FILE

Click on the CREATE A NEW BATCH OF TESTS button on the Welcome screen shown below:

۲





۲

NOTE: If the Welcome screen is not displayed, it can be displayed by clicking on the lcon on the toolbar.

A SAVE AS dialog will be displayed as shown below:

Save As					? ×
Save jn:	🗀 Data		•	🕝 🤌 📂 🖬	•
My Recent Documents Desktop My Documents	Test.batch				
My Computer My Network My Network Places	File <u>n</u> ame: Save as <u>type</u> :	Batch Files (*.batch	n)	•	Save Cancel

6 NEXYGEN PLUS Quick Start Guide

۲

Enter the required name for this test file noting that the file can be saved in any location, e.g. a networked folder.

 (\clubsuit)

Click on the SAVE button to display the TEST TYPE screen shown below:

Test Type				? ×
You must choose w Press Back to returr	hich type of te n to the other o	st is going to be categories.	performed in this b	atch.
Cycling Te	st			
□ Flexural Te	st st			
💭 Tear and F	'eel Test			
Tension or	Compression	Test		
L/ User Conrig	guradie i est			
	[1	
	< <u>B</u> ack	Finish	Cancel	Help

()

Decide which TEST TYPE is required using the criteria below:

1.2 CYCLING TEST

۲

The Cycling Test can be used for:

- Cycling between Load / Stress Limits
- Cycling between Extension / Strain Limits
- Cycling between Different Types of Limits
- Single Cycle or Multiple Cycles
- Fixed Number of Cycles
- Cycle for a Time Period
- Cycle until the Sample Breaks

1.3 FLEXURAL TEST

The Flexural Test can be used for:

- 3 Point Bend or 4 Point Bend
- Stop at Defined Load
- Stop at Defined Bending Stress
- Stop at Defined Extension
- Stop when Sample Breaks

NEXYGEN PLUS Quick Start Guide 7

NEXYGEN_Plus_.indd 7

9/8/2009 11:16:40 AM

1.4 FRICTION TEST

The Friction Test can be used for:

- Friction or Insertion / Extraction
- Stop at Defined Extension
- Stop at Defined Time
- Stop when Sample Breaks

1.5 TEAR AND PEEL TEST

The Tear and Peel Test can be used for:

- Tear / 90 Degree Tear / 180 Degree Tear
- T Peel / 90 Degree Peel / 180 Degree Peel
- Climbing Drum
- Stop at Defined Extension
- Stop at Defined Propagation
- Stop at Defined Time
- Stop when Sample Breaks

1.6 TENSION OR COMPRESSION TEST

The Tension or Compression Test can be used for:

- Pull to Break
- Pull To Limit

()

- Pull for a Time Duration
- Compress to Break
- Compress To Limit
- Compress for a Time Duration
- Apply a Constant Load Creep Test
- Measure Sample Relaxation e.g. Foam Test
- Measure Rubber Modulus
- Measure Ring Stiffness

1.7 USER CONFIGURABLE TEST

The User Configurable Test can be used for:

MULTI-STAGE TESTING

- Specialised Preconditioning before test
- Stop at Defined Extension
- Stop at Defined Propagation
- Stop at Defined Time
- Stop when Sample Breaks

Select the required TEST TYPE then click on the FINISH button.

8 NEXYGEN PLUS Quick Start Guide

()

()

This action will automatically create the Test File then display the TEST CONFIGURATION screen similar to the example screen shown below:

۲

eneral Purpose Tension/Co	mpression Test			
Basic Settings Sample Height	Pre-Test Questions			
Direction	Test Direction Direction: Tension			
Preload/stress	Test Options			
Preload/stress:	5.6 N	Test Automation		
Preload/stress Speed:	21 mm/mir 🗸	Video Capture		
Test Speed Extension rate:	100 mm/mir 💌	DAQ Device		
C Load rate:	50 N/min 🗸	Machine Settings		
O Stress rate:	10 MPa/s			
Automatically zero at the start of the test				
C Load only				
C Extension only				
Coad and Extension Return to zero extension	ОК			
		Cancel		

The actual screen displayed depends upon the selected TYPE OF TEST but the options for each type of test are similar to the example Tension/Compression screen shown above.

NEXYGEN PLUS Quick Start Guide 9

۲

9/8/2009 11:16:41 AM

۲

2.0 PERFORMING A TEST

2.1 PERFORMING A TEST

Click on the OPEN AN EXISTING BATCH button on the Welcome screen shown below:

(�)





۲

NOTE: If the Welcome screen is not displayed, it can be displayed by clicking on the lcon on the toolbar.

An OPEN dialog will be displayed as shown below:

Open						? X
Look jn:	🚞 Data		•	🔆 🦻	بي 🥙	
My Recent Documents Occuments Desktop	👬 chris.batch					
My Documents						
My Computer						
(File <u>n</u> ame:	*.batch			•	<u>O</u> pen
My Network	Files of type:	Batch Files (*.batch)			•	Cancel
Flaces		🔲 Open as read-only				

Select the required test file then click on the OPEN button.

NOTE: The above steps do not have to be performed if the test is run immediately after the test file has been defined as shown in the previous section.

10 NEXYGEN PLUS Quick Start Guide

۲

The graph screen will be displayed as shown below:

NEXYGEN Plus (Default -	Administrator - Superviso	rs) - [Test.batch]		_ 7 ×
File Edit View Tools 1	Test Help		and the second second second	X
		122 FT A B S S 日 日 S S 区 A M M M		
■ O hore by the set of the se				
	Vienda Lowes Lite	atotics (XBanTange) Mittagram / 4		*
	1/1			1 Rove
For Help, press F1		Internet line and line and		NUM
🖅 Stati 🕃 🗀 🧶 🗂	T C C C	ES36 /5 152 Tot. C Novo Nordek Ph. C Varo Control	NEXITUEN PLus C Song Transducer C system32	🔛 NEXYGEN Plu 🔣 🤘 💥 🖓 😓 Ve 10.33

 (\clubsuit)

Click on the green START TEST button at the left hand side of the graph to start the test.

The materials testing machine will move to perform the selected type of tests then the results will be calculated and stored in the data table.

To view the data table, click on the RESULTS tab at the bottom of the screen.

To return to the graph screen, click the GRAPH tab at the bottom of the screen.

To save the test file, select FILE, SAVE from the main menu.

For further information regarding the many features of the program, please refer to the comprehensive on-line help.

()

۲

9/8/2009 11:16:41 AM



Measurement and Calibration Technologies

Americas

۲

AMETEK Measurement & Calibration Technologies Chatillon Brands 8600 Somerset Drive Largo, Florida 33773 United States of America Tel +1-727-536-7831 Tel +1-800-527-9999 (USA Only) Fax +1-727-539-6882 chatillon.fl-lar@ametek.com

United Kingdom AMETEK

Lloyd Instruments Stevning Way Bognor Regis West Sussex PO22 9ST United Kingdom Tel +44 (0) 1243 833 370 Fax +44 (0) 1243 833 401 uk-far.general@ametek.co.uk

Shanghai Rm 912, Metro Tower 30 Tian Yao Qiao Road Shanghai 200030 China Tel +86 21 6426 8111 Fax +86 21 6426 7818 Ext 12 lloyd@ametek.com.cn

France AMETEK SAS Rond Point de l'Epine des Champs Buro Plus - Bat. D 78990 Elancourt France Tel +33 (0) 1 30 68 89 40 Fax +33 (0) 1 30 68 89 49 general.lloyd-instruments@ametek.fr

۲

Germany AMETEK Europe GmbH Rudolf-Diesel-Strasse 16 D-40670 Meerbusch Germany Tel +49 (0) 2159 9136-0 Fax +49 (0) 2159 9136-39 info@ametek.de

Pte. Ltd. 10 Ang Mo Kio Street 65 #05-12 Techpoint Singapore 569059 Tel +65 6484 2388 Fax +65 6481 6588 aspl@ametek.com.sg

out notice. While reasonable efforts have been made in the preparation of this document to assure its accuracy, AMETEK, Inc. assumes no liability resulting from errors or omissions in this document, nor from the use of the information contained herein. © 2009 by AMETEK, Inc. Information within this document is subject to change without notice.

۲

The material in this document is for information purposes only and is subject to change with-

Part No. 01/3366 September 2009

12 NEXYGEN PLUS Quick

Visit us on the web at www.lloyd-instruments.com Singapore AMETEK Singapore

۲

9/8/2009 11:16:41 AM

